



SIZING FOR AIR VALVE ASSEMBLY COVER				
VALVE SIZE	A (DIAMETER)	B (HEIGHT)		
1"	12"	36"		
2", 3", 4", & 6"	20"	36"		
8"	24"	36"		

PLAN IN SIDEWALK





NOTES:

- ENGINEER TO VERIFY THE REQUIRED SIZE AND TYPE OF AIR VALVE ASSEMBLY PER PROJECT REQUIREMENTS.
- USE ONLY THE APPROPRIATE STD. DRAWING(S) AND DESCRIPTIONS FOR CORRECT SIZE OF AIR VALVE ASSEMBLY.
- MODEL NO. P6002001, 2 or 3 BY AMORCAST 1-818-982-3600.
- ALL EXPOSED FERROUS METAL SHALL BE COATED PER SPECS. EXTERIOR COLOR TO BE SANDSTONE FINISH.

J.C.	12/12/16	SAN BERNARDINO MUNICI	PAL WATER DEPARTMENT	DRAWING
D.D.M.	MAR. 16	A DMODOACT (D/		NUMBER
D.D.M.	JAN. 11	ARMORCAST (PO	SBMWD	
C.L.R.	NOV. 05	ENCLOSURE FOR AIF		
REVISION	DATE			₩7.6
SCALE:	NONE	APPROVED WARREN HUANG, P.E. RCE 45	DATE 07/04/2019	-